

Getting Started

EB Classrooms

Starting Class

To turn the power on for the equipment, press the “Start Class” button on the AMX touch panel located on the lectern. (If the screen is blank, touch the screen to wake up the system.) Pressing the “Start Class” button will start the projector, lower the screen and sets the host computer as the input source. The touch panel screen will display a screen that will say that the system is warming up and will display a countdown until the system is ready.

AMX Touch Panel

The following are the buttons you will see on the AMX touch panel located on the lectern:

Source Controls:

- Host PC: Selects the lectern’s computer. This is selected automatically when the system is started.
- Laptop : Selects a user-provided laptop that can be connected to the cables (video and audio) located on the lectern. Internet connectivity is accessible for laptops only through UAB WiFi, which requires a BlazerID and password.
- Document Camera: Selects the Document Camera. Make sure to turn on the power on the document camera. All the lights on the documents cameras control panel should be BLUE.
- DVD : Selects the DVD player. All controls for the DVD player will appear in the middle section on the touch panel. There will be a “Menu Control” button that will bring up a screen with navigation controls so that you can access different portions of the DVD. Select the “Play Back Control” to return to the regular controls.
- VCR : Selects the VCR. All controls for the VCR player will appear on the touch panel.

Other Controls:

- Home : Clears the middle section of the touch panel.
- Help : Displays the phone number to call if you are having problems with the equipment in the room.
- Picture Mute: Displays a black screen from the projector so students will not see image from source.
- Volume Up: Turns up the volume from the source.
- Mute : Mutes the audio from the source.
- Volume Down: Turns down the volume from the source.

Other Notes

USB / Flash Drives: A cable is provided on the top of the lectern near the LCD monitor that may be used for USB / Flash drives.

Volume: All volume is controlled by touch panel.

For **laptop** users, a mini audio cable connected to system is provided, and is laid out on the right side of the lectern for hook up to the mic port on your computer. Please be aware of the laptop’s volume setting.

Document Camera: After selecting the Document Camera from the AMX touch panel, make sure that you turn on the power to the document camera. The lights on the front of the document camera should be BLUE. Also note the Zoom, Bright (light/dark settings), and Freeze (which freezes the display image until button is hit again) controls on the presenter.

For **Transparencies** there is a separate button located on the left edge of the transparency device on the top of the document camera.

Please remember to turn the document camera off when you are finished using it.

Remote: In the drawer on the right side of the lectern there is a remote that will control PowerPoint presentations. The remote has four (4) buttons: Forward, Back, a laser pointer and blank screen.

Lectern: The left door on the front of the lectern will remain unlocked for access to the computer's CD drive, DVD player and VCR.

Screen Controls: If you need to use the screen with out powering up the room, there are manual controls on the wall to the left of the lectern.

Ending Class

When you are finished using the room, press the "END CLASS" button on the AMX touch panel. A confirmation screen will appear asking if you are sure that you want to power down the equipment. Press the GREEN "ABORT! Continue Class" button to continue using the system. To end the class press the RED "System Off" button. This will raise the screen and turn off the projector, DVD player and VCR.

Please make sure to log off the Host CPU that is in the lectern and that the document camera is turned off (power button will turn from BLUE to RED.)

NOTE: Once the class has ended, the projector must cool down for two minutes. The system will not allow you to restart until this cool down has completed.

HELP

If at any point you need assistance, please call AskIT at 6-9999.